

BUBBA|STORAGE

QUICK START GUIDE




INSTALLATION GUIDE

① Check package contents

- Bubba|Storage
- 4 rubber feet
- Wall power adapter
- Mains power cable, fitting your country's standard
- eSATA cable

② Attach the rubber feet

Decide if you want to use Bubba|Storage standing upright or lying down. Attach the feet accordingly.



③ Connect your BUBBA|STORAGE

- Connect the eSATA cable between the Bubba|Storage and your Bubba|Two.
- Connect the 12V power adapter first to a mains supply, and then to Bubba|Storage.
- Log in as administrator on your Bubba|Two; click 'Disk' and click 'Connect' next to the new disk.

④ Accessing your BUBBA|STORAGE

- Accessing Bubba|Storage via samba you will find your files under `bubba\storage\extern\[disk_name]`.
- Accessing Bubba|Storage with a web browser using Bubba|Two File manager you will find your files under `/home/storage/extern/[disk_name]`.

⑤ Disconnecting your BUBBA|STORAGE

Log in as admin on your Bubba|Two; click 'Disk' and click 'Disconnect' next to the new disk. Now it is safe to remove the power from Bubba|Storage.

⑥ Using BUBBA|STORAGE for RAID, LVM or backup

Read your Bubba|Two manual to configure a RAID setup, an LVM extension or a backup job towards your Bubba|Storage.

The complete user's manual is available for download at www.excito.com, click 'Support'.



Note: To prevent loss of data or malfunction, always disconnect Bubba|Storage properly before unplugging it.

For a richer BUBBA|STORAGE experience - visit

www.excito.com

forum.excito.net

